SCHWEIZER AIRCRAFT CORP.

Supplement to the Approved Rotorcraft Flight Manual

For

Schweizer 330 Model 269D Helicopters

ENGINE AIR PARTICLE SEPARATOR FILTER

WARNING: THIS DOCUMENT, OR AN EMBODIMENT OF IT IN ANY MEDIA, DISCLOSES INFORMATION WHICH IS PROPRIETARY, IS THE PROPERTY OF SIKORSKY AIRCRAFT CORPORATION AND/OR ITS SUBSIDIARIES, IS AN UNPUBLISHED WORK PROTECTED UNDER APPLICABLE COPPRIGHT LAWS, AND IS DELIVERED ON THE EXPRESS CONDITION THAT IT IS NOT TO BE USED, DISCLOSED, REPRODUCED, IN WHOLE OR IN PART (INCLUDING REPRODUCTION AS A DERIVATIVE WORK), OR USED FOR MANUFACTURE FOR ANYONE OTHER THAN SIKORSKY AIRCRAFT CORPORATION AND/OR ITS SUBSIDIARIES WITHOUT ITS WRITTEN CONSENT, AND THAT NO RIGHT IS GRANTED TO DISCLOSE OR SO USE ANY INFORMATION CONTAINED HEREIN. ALL RIGHTS RESERVED. ANY ACT IN VIOLATION OF APPLICABLE LAW MAY RESULT IN CIVIL AND CRIMINAL PENALTIES.

EXPORT WARNING: THESE COMMODITIES, TECHNICAL DATA OR SOFTWARE ARE SUBJECT TO THE EXPORT CONTROL OF EITHER THE INTERNATIONAL TRAFFIC IN ARMS REGULATIONS (ITAR) OR THE EXPORT ADMINISTRATION REGULATIONS (EAR) AND CANNOT BE EXPORTED WITHOUT THE PRIOR AUTHORIZATION OF EITHER THE DEPARTMENT OF STATE OR THE DEPARTMENT OF COMMERCE. THE TERM (EXPORT(INCLUDES ANY DISCLOSURE AND/OR PROVISION OF ACCESS TO COMMODITIES, TECHNICAL DATA OR SOFTWARE TO OR BY FOREIGN NATIONALS (WHETHER LOCATED IN THE UNITED STATES OR ABROAD). THIS REQUIREMENT ALSO APPLIES TO FOREIGN NATIONALS (WHETHER LOCATED IN THE UNITED STATES OR ABROAD). THIS REQUIREMENT ALSO APPLIES TO FOREIGN NATIONAL EMPLOYEES OF U.S. COMPANIES AND THEIR FOREIGN SUBSIDIARIES.

Date of Approval: NOV 2.8 1994

Approved By: X. Ollima

Irwin N. Brumer Manager, NYACO, ANE-170

LOG OF PAGES

PAGE	DATE	
1	28 Nov 1994	
2	28 Nov 1994	
3	28 Nov 1994	
4	28 Nov 1994	
5	28 Nov 1994	
6	28 Nov 1994	
7	28 Nov 1994	
8	28 Nov 1994	

REVISION TABLE

Date	Description
	Date

INDEX

Paragraph Number	Title		Page No.
	Section I	General	5
	Section II	Limitations	5
	Section III	Emergency and Malfunction	
		Procedures	6
	Section IV	Normal Procedures	
4.1	Preflight Inspection	6	
	Section V	Performance Data	
	Section VI	Weight & Balance Data	7
	Section VII	Aircraft Handling, Servicing &	
	Maintenar	ice	7
7.1		Cleaning and Inspection	
	Section VIII	Additional Operations &	8
		Performance Data	

This page is intentionally left blank.

SECTION I

General

This supplement must be carried in the applicable basic FAA approved 330 Model 269D Rotorcraft Flight Manual when the rotorcraft is equipped with the Optional Engine Air Particle Separator Filter. Except as modified by this flight manual supplement, operation in compliance with the basic approved Rotorcraft Flight Manual is mandatory.

The Engine Air Particle Separator provides filtration of engine air. The installation incorporates a particle separator filter, a bleed air operated ejector system, and a gas spring operated bypass door. The particle separator unit filters engine intake air by imparting centrifugal force to separate heavy dirt particles from the mainstream of air entering the engine. The ejector system, powered by engine compression air, boosts the scavenge velocity increasing the efficiency of particle removal, and ejects the dirt out of the aircraft. Should differential pressure exceed set limits, the gas spring allows the bypass door to open, providing an alternate air path to the engine plenum chamber. An indicator light on the instrument panel illuminates when the bypass door is activated.


SECTION II

Limitations

Not Affected

SECTION III

Emergency



- Amber ALT AIR Indicator Illuminates Indicating air bypass door is activated
- Monitor engine instruments
- • Land as soon as practicable
- • Service Particle Separator before next flight (HMI Appx A)

SECTION IV

Normal Procedures

4-1. PILOTS PREFLIGHT INSPECTION

INTERMEDIATE FUSELAGE LEFT SIDE

Engine air filter for obstructions and damage CHECK

Engine air filter ejector tube for obstructions and damage CHECK

SECTION V

Performance

5-1. When making a power check use the internal screen inlet power check chart (Model 269D Pilot's Flight Manual, Fig. 5-8) in the normal manner except, reduce recorded T.O.T. by 11°C at the test torque.

SECTION VI

Weight and Balance

6-1. At the time of delivery, Schweizer Aircraft Corporation provides each rotorcraft with an original weight and balance report and a list of equipment (equipment both required and optional) installed on the helicopter at the time of licensing. The removal or addition of any equipment can affect the basic empty weight and center of gravity. Any change to the permanently installed equipment or modification which affects weight or moment must be entered in the weight and balance record.

SECTION VII

Handling, Servicing & Maintenance

7-1. CLEANING AND INSPECTION

- a. Open lower access door to plenum chamber.
- b. Cover engine air inlet port
- c. Visually check for obstruction or debris in filter. Vacuum any debris from tubes and ejector passageway. Use compressed air to blow out any contaminates.
- d. Wash the filter assembly using a pressurized solution of soap and water then rinse thoroughly to remove any cleaning solution from filter assembly and plenum chamber.
- e. Use compressed air to dry and remove excess moisture from the filter assembly. Remove any standing puddles of water inside the plenum chamber.

Issued: 28 Nov 1994 7

SECTION VIII

Additional Operations and Performance Data

- **8-1.** Decrease calculated specific range by 3%.
 - Increase calculated fuel flow by 3%.